



LUBRISTYL PRECISION OIL PEN (REFILLABLE)

Model: 84652



Description



The precision oil pen sucks back excess oil!

Instructions:

Keep the needle as vertical as possible on the to be lubricated surface and apply a light pressure with the pen. The first time it takes a little longer for the oil to flow.

To suck back excess oil: create a vacuum by quickly pressing and releasing the pen with the needle in the oil. Make circular movements in the oil to increase the suction effect.

Finish each lubrication with this procedure to empty the needle and to avoid dripping.

To fill:

- 1. carefully unscrew the head with the needle from the oil reservoir
- 2. leave the O-ring on the wire of the metal head
- 3. fill the oil reservoir with your oil
- 4. screw the head back onto the reservoir and keep it in line. Make sure that the Oring is pressed lightly.

The Lubristyl oil pen is robustly built and will continue to function as long as the needle is straight and not clogged.

Caution: The Lubristyl oil pen cannot and should not be used as a medical injection needle. Although the needle is not sharpened, users should use the pen carefully to avoid injury. Not intended for children. Pre-filled with a mineral oil with additives.

Smeertechniek Rotterdam

Cairostraat 74 3047 BC Rotterdam

T 010 - 466 62 55

F 010 - 466 66 55

E info@smeertechniek.nl

W www.smeertechniek.nl

Scan the QR code to order this product

